



Instruction manual for *Magic Mag* mosquito screens

First of all:

- Clean the window or door frame with window cleaner or an alcohol based cleaner so as to ensure that the surfaces are clean.
- Find the right surface to install the screen:
 - If your door opens IN, install the screen on the outside of the door frame.
 - If your door opens OUT, install the screen inside the door frame.
 - For sliding doors, install the screen on the outside of the door frame.

Follow the instructions:


1. Find and mark the centre of the top of your door frame.

2. Lay out your **Magic Mag** screen on the floor with the magnets lined up in the centre (fig. 1). You will see how the upper part of the screen has a larger gap between the magnets and the upper edge, so be careful to position the screen the right way up.

3. Check that each magnet attracts its opposite magnet.

4. Apply the adhesive holders (from 1 a 12) as shown in the figures (see fig. 2, 3, 4 e 5).


N.B. The screen material is held between the holders.





(fig. 2)




(fig. 3)




(fig. 4)




(fig. 5)





4. Peel the adhesive backing off the velcro strips (see letter **V**) and apply to the screen as shown in the (fig. 6).





(fig. 6)



5. Next apply the screen (**using the adhesive side of the adhesive holders and the velcro**) to the frame of the door or window, taking care that the centre of the screen meets the centre of the frame as described in Point 1. (For the best installation make sure that the screen is high enough to stop it dragging on the ground).



6. Ensure that the magnets are correctly aligned and meet at the centre.
7. Apply the upper holding strip with the adhesive velcro.



Helpful tips:

- For frames in steel or aluminium, only use the adhesive velcro strips.
- For frames in plastic, PVC or wood, use either the velcro adhesive strips or drawing pins (not included).
(Remember that if you use drawing pins the wood will have small holes afterwards).
- If the magnets don't click shut perfectly, adjust the width of the screen to ensure that the holders and the velcro are well-positioned and well-attached to the screen and the frame.

Cleaning and storage:

- To clean the screen use only a damp cloth with tepid water. For stubborn dirt, use a small amount of soap and a cloth.
- Before winter storing, make sure the screen is perfectly dry.
- Do not put in dryer. Do not dry-clean.

Safety information:

- Keep children away from the packaging material (danger of suffocation). Dispose of the material in appropriate recycling containers.
- Keep away from sources of heat such as stovetops, ovens, cigarettes, ashtrays, boiling liquids or incandescent materials.
- Because of possible electromagnetic interference, anyone with implanted medical appliances, such as pace makers, should check with their doctor before installing the screens.
- Handle drawing pins or any other metal objects not supplied carefully.
- Be careful that children under the age of 16 do not play or swallow any of the parts of the **Magic Mag** screen. In the case of any unexpected incident, consult your doctor immediately.
- **The product might not function correctly if it is not correctly installed.**

Warning:

- The Magic Mag screen should not be used as a barrier for children or pets.
- Do not use the Magic Mag screen together with a double door, otherwise children or pets might not be able to pass through it.

Some further advice for installation:

- The mosquito screen must not be stretched too much
- The mosquito screen must be perpendicular and not drag on the pavement
- It is recommended to fix the central adhesive holders on the upper part slightly higher (5-10 mm) than the other adhesive holders fixed on the upper part of the door frame to facilitate the closure of the magnets fixed at the centre of the mosquito screen (if necessary, this should be done at the end of the installation procedure outlined in the manual).

For more information, please contact



Via Adelaide, 56
06128 Perugia - Italy
Vat. 03419660547
Fax. +39.075.9660551
E-mail: info@magicmag.it
Web: www.magicmag.it
Web: www.gblservice.eu